

PLC原廠行貨

√ 原廠正貨(行貨) Official Export Product



LANGUAGE

英文版本 原廠正貨 English version – genuine product guaranteed

• 官方中文及英文用戶指南 Official English & Chinese User Guides

安全程度 SECURITY LEVEL

售後服務 AFTER SALES


SERVICE

更安全 More secure

• 原廠安裝配件 Original parts for local installation use



- 原廠感應保養卡 RF Warranty Card
- 2年產品保養證 2-Year Product Warranty
- 經PLC專業技術人員上門安裝, 可享有1年安裝保養服務。





• 官方的客戶服務熱線及維修中心 Official Customer Service Hotline & Maintenance Centre

DISCLAIMER: All information are subjected to change at anytime without prior notice by The PLC Group or its associated partners/suppliers. Should there be any variations in product functionality, outlook, technical specifications, documentation, service, warranty, promotions and/or pricing, the actual offering at the time of purchase shall be the confirmed version.

• The catalog information is for reference only. For updated details, please contact The PLC Group

- In case of dispute, The PLC Group reserves the right to final decision.

 If there is any inconsistency or conflict between English and Chinese version, the English version shall prevail.

SAMSUNG SMART Doorlock names and logos are registered trademarks and properties of SAMSUNG SDS CO. LTD., any use without prior written consent ids prohibited. Copyright® 2019 All rights reserved.

Realize your vision SAMSUNG SDS

SAMSUNG SMART Doorlock Available at Selected Official Dealers






只在特約正貨商號有售

香港及澳門代理 DISTRIBUTOR For HONG KONG & MACAU









3 modes of access SHP*DH537



Code



RF Sticker

智能防盜功能

鎖定安全把手鍵 Safety Button

Tag / Card

Anti-Theft Features

從室內打開門,用戶拉下把手時必須同時按下

安全鍵才能開門,大大提高門鎖的防盜性能。

To open the door from within, users simply press the button and turn the

handle therefore preventing any potential outside break-ins from intruders.









KEY

貼心功能 Thoughtful Design

低電量提示 Low Battery Alert

門銷將在雷池雷量不足 或需要更換時涌知您。

Doorlock will notify you when the batteries are low and need to be replaced.



音量控制 Volume Control

開鎖提示音音量調較。 (3個級別,包括靜音) Adjustable volume or mute.



GCOD DESIGN



先按下隨機數字再按密碼, 防止盜賊盜 取指紋來開門。

Enter random digits before your password to reduce risk of intruders checking fingerprints.

雙重驗證 Double Authorization

用戶需輸入密碼和拍卡才可打開門鎖。

Require password & RF Tag / Card combination to unlock.

外出防盜模式 Anti-theft Mode

一旦設置了這種模式,當盜賊試圖從室內離 開時,門鎖警報會立即響起。





Once you set up this mode, the alarm sounds when a thief tries to exit from the door.

連續輸入5次錯誤密碼,門鎖會停止操作3 分鐘。如入侵者試圖從門外強行打開門鎖, 警報會即時啟動。

attempt to force open the door.



安全鎖定模式和警報 Security Lockout Mode & Tamper Alarm

Lock stops operating for 3 minutes with 5 invalid PIN code attempts. The lock will sound if intruders



